

AM1000 Reverting back to the crystal

First remove the AM1000F module, remove the two nylon screws and gently rock the AM1000F to remove it from the socket. You can leave the two nylon standoffs if you want or they can be removed from the bottom. Install the CD4001 chip being careful to place the notched end down as shown. Be sure all pins are in the socket. Now you can install the crystal in the Y1 socket area.

